Instructions for wear The equipment must be checked for Proof of correct operation and safety, especially checks of play equipment maintenance the points listed below: Support frame Playground..... 1. Clean with stainless steel spray using a clean Date of installation cloth. Checks depend on the type of equipment. **Mechanical parts** Any equipment with moving parts must be checked at least twice a year, static 2. Check that disc can be turned freely, clean equipment at least once a year. bearings of the disc if necessary. Intervals for maintenance work and checks Acrylic glass/Makrolon generally depend on 3. Clean with commercially available - the location dishwashing liquid or, better still, plastic - the usage cleaner (www.burnus.de), under no - the frequency of use circumstances use spirits or turpentine! - possible vandalism Structural stability For more details see also "General instructions for maintenance of 4. In order to check the fixation to the ground or playgrounds". for corrosion, uncover the foundations once a year. Turning Circle Order No. 10.13105 Moiré disc Order No. 10.14005 1 Special notes, e.g. for repairs Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action All work carried out, everything is in order Maintenance carried out by: Date