Instructions for wear checks of play equipment	СО	The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
Playground		Wooden parts			
Date of installation	1.	Check for rot and, if necessary, smooth splinters and round off sharp edges of cracks.			
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	2.	Check all bolts and screws are tight and retighten if necessary.			
Intervals for maintenance work and checks generally depend on	3.	Recommendation: Apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.			
- location		Structural stability			
<ul><li>kind of use</li><li>frequency of use</li><li>possible vandalism</li></ul>	4.	In order to check steel bracing for corrosion, uncover the foundation once a year.			
For more details see also "General instructions for maintenance of playgrounds".					
Support Frame for Rope Bridge Order No. 3.66623/3.66633				Special notes, e. g. for repairs	
		pair not carried out, it is still possible play on equipment			
		pair not carried out, uipment is taken out of action			
		work carried out, erything is in order			
	Ма	intenance carried out by:		+	
		Date			