## Instructions for wear checks of play equipment

## Playground .....

Date of installation .....


Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.

Intervals for maintenance work and checks generally depend on

- location
- kind of use
- frequency of use
- possible vandalism

## For more details see also "General instructions for maintenance of playgrounds".

## Climbing Structure 18 Order No. 6.51018/L6.51018



cc	ne equipment must be checked for prrect operation and safety, especially e points listed below:	Proof of maintenar
	Wooden parts	
1.	Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.	
2.	Check that all bolts/screws and all wood connections are tight and retighten if necessary.	
3.	<b>Recommendation</b> : apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.	
	Ropes and rope nets	
4.	Check for wear and tear, if worn heavily, it is imperative they be replaced.	
5.	Check connections and swages.	
	Structural stability	
6.	In order to check for rot at wooden parts or steel feet for corrosion, uncover the foundations once a year.	Special notes, e.g. for repairs
	pair not carried out, s still possible to play on equipment	
	pair not carried out, uipment is taken out of action	
eq Al		