## The equipment must be checked for correct Instructions for wear operation and safety, especially the points Proof of checks of play equipment maintenance listed below: Wooden parts Playground ..... Date of installation ..... 1. Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. Checks depend on the kind of equipment. Check that all bolts and screws are tight and Any equipment with moving parts must be retighten if necessary. checked at least twice a year, static equipment at least once a year. **Recommendation**: apply paraffin wax to the upper end grain areas once a year, please Intervals for maintenance work and checks generally depend on: refer to Order No. 0.90100, 1 litre. Check the ash wood rungs of the ladder for - location wear and tear, the remaining diameter must - kind of use be at least 30 mm. - frequency of use - possible vandalism Structural stability For more details see also "General instructions for maintenance of In order to check for rot at wooden parts playgrounds". and steel feet for corrosion, uncover the foundations once a year. Play Wall 01 Combination equipment Order No. 8.50001 Please pay attention to the separate maintenance notes of the following combination equipment: Drawing Board 4.24460 Sand Play Equipment 3.19100 Sand Chute 5.97090 Fireman's Pole 3.69480 Note Special notes (e. g. for repairs) Please check that all documents are included! Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment ist taken out of action All work carried out, everything is in order Maintenance carried out by For spare parts refer to back of page. ...... Date ......

## Spare parts Play Wall 01 Order No. 8.50001

Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts.** 

rder No.	Spare part	Order No.	Spare part
7000	sand hoist, complete	0.97075	sand tray
97010	protection block with turn round roll	99.00420	block for sand tray
7020	replacement chain, complete	99.00320	upper part for sand tray
√ <sup>3</sup> 07030 ♠	tyre segment		
		0.97130	sand wheel
97032	tyre segment with chains	0.97283	ladder, 5 rungs
7140	tyre segment without chains	0.98360	single rung
07050	shovel with chain		0
7100	mounting plate, top		
7110	mounting plate, bottom		
<b>7090</b>	sand chute, bent		