Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
Playground		Wooden parts		
Date of installation	1.	Check for rot and, if necessary, smooth splinters and round off sharp edges and		
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	2.	cracks. Check that all bolts and screws are tight and retighten if necessary.		
Intervals for maintenance work and checks generally depend on	3.	Check the ash wood rungs of the ladders for wear and tear, the remaining diameter must be at least 30 mm.		
locationkind of usefrequency of usepossible vandalism	4.	Recommendation: Apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.		
For more details see also "General instructions for maintenance of playgrounds".	5.	Structural stability		
		In order to check the steel feet for corrosion, uncover the foundation once a year.		
End Frame for Chain Path Order No. L3.66220				
Order No. 3.66224 in square timber with steel feet				
4				
				Special notes, e.g. for repairs
		pair not carried out, s still possible to play on equipment		
5		pair not carried out, uipment is taken out of action		
	1	work carried out, erything is in order		
	Ma	intenance carried out by:Date		