Instructions for wear	The equipment must be checked for correct operation and safety, especially		of
checks of play equipment	the points listed below:	Proof of maintenance	
Playground	Wooden parts		
Date of installation	 Check for rot and, if necessary, smooth out splinters and round off sharp edges of 		
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	 Check that all bolts and screws are tight and retighten if necessary. 		
Intervals for maintenance work and checks generally depend on	3. Recommendation : apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.		
locationusage	Structural stability		
frequency of usepossible vandalism	 In order to check steel feet for corrosion, uncover the foundations once a year. 		
For more details see also our general instructions for maintenance of playgrounds!			
Middle Pentagonal Tower Order No. 3.52000			
			Special notes, e.g. for repairs
	Repair not carried out, it is still possible to play on equipment		
	Repair not carried out, equipment is taken out of action		
	All work carried out, everything is in order		
	Maintenance carried out by:		