Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance	
Playground	Wooden parts		
Date of installation	Check for rot and, if necessary, smooth out splinters and round off sharp edges of		
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	cracks. 2. Check that all bolts and screws are tight and retighten if necessary.		
Intervals for maintenance work and checks	Serpentine Ladder		
generally depend on - location - usage	Check connection to wood, if necessary retighten screws/bolts (see detailed diagram).		
- frequency of use - possible vandalism	4. Check ropes for wear and tear, if the steel reinforcement is damaged it is imperative it be replaced.		
For more details see also our general instructions for maintenance of			
Serpentine Ladder with beam, for towers Order No. 3.69410	5. Check the anchoring to the ground once a year. 5. Check the anchoring to the ground once a year.		
Serpentine Ladder for Platforms Order No. 3.69412 1.50 m Order No. 3.69413 2.00 m			
3 2		Special notes, e.g. for repairs	
	Repair not carried out, it is still possible to play on equipment		
	Repair not carried out, equipment is taken out of action		_
Detail	All work carried out, everything is in order		_
5	Maintenance carried out by:Date		