

Instructions for wear checks of play equipment

The equipment must be checked for correct operation and safety, especially the points listed below:

Proof of maintenance

Playground.....

Date of installation


Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.

Intervals for maintenance work and checks generally depend on

- location
- usage
- frequency of use
- possible vandalism

For more details see also our general instructions for maintenance of playgrounds!

Caterpillar - Type 02
Order No. 5.00015



Wooden parts

1. Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.
2. Check that all bolts and screws are tight and retighten if necessary.
3. If required, touch up or renew paintwork.

Coloured discs

4. Check for damage.

Rotating discs

5. Check that bearings move smoothly.
6. Ensure mounting bracket is securely connected and check for wear and tear.
7. Clean surface and cover up scratches with matching colour of acrylic paint, if necessary.

Antennae

8. Check that antennae are securely connected.
9. Replace if steel reinforcement is damaged.

Structural stability

10. In order to check for rot at wooden parts and steel feet for corrosion, uncover the foundations once a year.

Special notes, e.g. for repairs

Repair not carried out, it is still possible to play on equipment

Repair not carried out, equipment is taken out of action

All work carried out, everything is in order

Maintenance carried out by:

..... Date