Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Joints	
Date of installation	 Check that swivel joint moves smoothly (remove sand which has accumulated around the support foot). 	
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static	 Check that main joint moves smoothly. 	
equipment at least once a year. Intervals for maintenance work and checks	 Check that the joints of the excavator arm and excavator bucket move smoothly. 	
generally depend on	 Apply grease to the lubricating nipple on the bucket joint. 	
- location - usage	Brake	
- frequency of use	Diake	
- possible vandalism	 Perform operational test: when load is placed on the seat, it should be possible to turn the platform; with no load placed 	
For more details see also our general instructions for maintenance of playgrounds!	on the seat, any turning movement should stop immediately. Replace rubber buffer if worn down.	
	Excavator bucket	
Large Excavator Order No. 5.30000	 File down any sharp edges on the shovel caused by wear and tear. 	
	Seat	
	 Check condition of seat surface, smooth if necessary. 	
	Lubrication	
	 If necessary, lubricated with suitable grease (universal grease) 	
8	Structural stability	repair
9	9. Check anchoring to the ground once a year.	Special notes, e.g. for repairs
	Repair not carried out, it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:	
	Date	



